

### FUJI – Wall Pad Installation Instructions

Snap a chalk line level with the desired height of your pads from the floor. [72" typically standard]. Check your work with a bubble-level as you go. Ensure the pads are plumb and level.

Layout your wall pads before your FUJI Mats are installed and secured. You may lay them approximately in place, allow for the ½" lip to slide behind the mats and sit on your floor.

Center Logos or custom cut-outs as needed first. Arrange the rest of your pads to test the layout.

The bottom lip may be custom sized to the thickness of your mat. If it is, set the pad in place and secure to the wall on the top lip first.

#### Concrete / Block / Brick:

- Use a Wood Bit to Pilot holes in the lip of the pad.
- Use a Masonry bit to pilot the hole in the wall, with the pad held in place.



- Secure to the wall using your masonry anchor (tapcon screws or toggle bolts, etc)
- Repeat for the bottom lip.



Fit your mats snugly beneath the pads when complete, if you need to make cuts to your mats, bury the cut edge underneath the wall pad, as the padding will overhang the mat edge by 1.5".

Call us if you have any questions, we're happy to help!